HARDWARE

DIN RAIL

FUNCTION

This rail is used to attach the i.Lon server to the wall, to equipment or in the enclosure. It is 8 inches long and slotted galvanized steel.

The rear of the i.Lon server enclosure contains a spring-loaded DIN rail lock, which securely grabs the DIN rail onto which the enclosure is snap, mounted. To release the enclosure from the DIN rail, insert a flathead screwdriver into the DIN rail locking tab and gently pull the tab upwards and away from the enclosure.

LENCORE
COMFORT. PRIVACY. INTELLIGIBILITY.