




NOTICE

All G7225 Operating Platform Rack Mount units are shipped with an OP sequence number of 1. To adjust the OP sequence number follow the instructions below:





Setup:

- 1) Disconnect all data cables from the OP.
- 2) Power up the OP.
- 3) Press enter on the keypad after the OP has completed the boot up process.


Configuration:

Press  until "Config" is displayed.

Sequence the OP number:

Press  until "Config Sequence, Pick OP#" is displayed. Press  or  to pick the OP #, then press .

Display 2 will display "Config Sequence, ****Success****." The OP must be power-cycled after changing the OP number for proper operation.

Note: If the OP is not rebooted, a "Network Error, Enter to retry" is displayed. Pressing  at this point will not remedy the network error.

*****Important: All Rack Unit OPs must have a unique OP# from 1 to 199.**

Testing:

- 1) Power cycle the OP.
- 2) Verify that the correct OP number shows in the display.

If you continue to have trouble adjusting the sequence number for the OP Rack Unit, Please contact Lencore Tech Support at 516-802-7879 or support@lencore.com.